

Edge Angel SRL

Part #	Length	Description
10908	20'	1" HD Nylon Webbing w/Carabiner, Swivel Top, Snap Hook, Boot Cover
10920	20'	3/16" HD Galvanized Cable SRL w/Carabiner, Swivel Top, Snap Hook, & Boot Cover
10922	25'	3/16" HD Galvanized Cable SRL w/Carabiner, Swivel Top, Snap Hook, & Boot Cover
10925	30'	3/16" HD Galvanized Cable SRL w/Carabiner, Swivel Top, Snap Hook, & Boot Cover
10924	50'	3/16" HD Nylon Coated Galvanized Cable w/Carabiner, Swivel Top, Snap Hook, & Tag Line
10927	50'	3/16" HD Stainless Steel Cable w/Carabiner, Swivel Top, Snap Hook, & Tag Line
10928	65'	3/16" HD Stainless Steel Cable w/Carabiner, Swivel Top, Snap Hook, & Tag Line
10931	20'	3/16" HD Stainless Steel Cable w/Swivel Top, Swivel Snap Hook, & Boot Cover
10933	25'	3/16" HD Stainless Steel Cable w/Swivel Top, Swivel Snap Hook, & Boot Cover
10936	30'	3/16" HD Stainless Steel Cable w/Swivel Top, Swivel Snap Hook, & Boot Cover



Compliant with all OSHA 1910, OSHA 1926 Subpart M, ANSI Z359.14-12, and ANSI A10.32-2012 regulations.

Class B SRL-LE. Average Arrest Force: 900 lbs. Maximum Arrest Force: 1,800 lbs.



Personal Fall Arrest: Edge Angel SRLs may be used in Personal Fall Arrest applications to support a MAXIMUM 1 Personal Fall Arrest System. Structure must withstand loads applied in the directions permitted by the system of at least 5,000 lbs. Maximum free fall is 2'. SRL may be positioned no more than 2' below harness dorsal D-ring. Applicable D-ring: Dorsal.



Restraint: Edge Angel SRLs may be used in Restraint applications. Restraint systems prevent workers from reaching the leading edge of a fall hazard. Always account for fully deployed length of SRL. Structure must withstand loads applied in the directions permitted by the system of at least 1,000 lbs. No vertical free fall is permitted. Restraint systems may only be used on surfaces with slopes up to 4/12 (vertical/horizontal). Applicable D-rings: Dorsal, Chest, Side, Shoulder.

Suitable for use in Leading Edge (LE) applications.

Setback distance: As determined by product testing, Guardian Fall Protection Edge Angel SRLs **MUST** be installed a **MINIMUM 6' (1.8m)** from the leading edge of applicable fall hazard(s).

Anchor point MUST NOT be lower than the leading edge of applicable fall hazard(s).

The allowable angle of redirection of the lifeline portion of Edge Angel SRLs at the leading edge of a fall hazard **MUST** be at least 90°.

Edge Angel SRLs may be used in stationary applications ONLY.

Attach Edge Angel SRL carabiner to selected anchorage connector, and attach snap hook to applicable harness D-ring.

Prior to use, a Competent Person MUST calculate appropriate fall clearance.